



- 26
- 25
- 24
- 0v 23
- 24v 22
- 21
- 0v 20
- 19
- 24v 18
- 17
- 24v 16
- 15
- 14
- 13
- 12
- 11
- 0v 10
- 9
- 8
- 7
- 6
- 24v 5
- 0v 4
- 3
- 2
- 0v 1

- in 12v 0v A B 0v
- 27. 28. 29. 30. 31. 32.

drukknop
half open

Doorcontrol-1500-V7	
	aansluitschema drukknop half open
RvD	30-12-2014.