





- 26 /
- 25 /
- 24 /
- 0v 23 /
- 24v 22 /
- 21 /
- 0v 20 /
- 19 /
- 24v 18 /
- 17 /
- 24v 16 /
- 15 /
- 14 /
- 13 /
- 12 /
- 11 /
- 0v 10 /
- 9 /
- 8 /
- 7 /
- 6 /
- 24v 5 /
- 0v 4 /
- 3 /
- 0v 2 /
- 1 /



Doorcontrol-1500-V7	
	Connection diagram Main current
RvD	30-12-2014.