


Photocell sender / receiver



When connecting the photocell, remove the bridge between terminal 21 and 21

Doorcontrol-1500-V7	
	Connection diagram Photocell relay
RvD	10-1-2017.